

QUICK START GUIDE

Applicable Model: G2




Safety Precautions

Before installation, please read the following safety precautions for user safety and to prevent device damage.


- Do not install the device in a place subject to direct sun light, humidity, dust or soot.
- Do not place magnet near the product. Magnetic objects such as magnet, CRT, TV, monitor or speaker may damage the device.
- Do not place the device next to heating equipment.
- Do not let liquid like water, drinks or chemicals leak inside the device.
- Do not let children touch the device without supervision.
- Do not drop or damage the device.
- Do not disassemble, repair or alter the device.
- Do not use the device for any purpose other than those specified.
- Clean the device often to remove dust on it. While cleaning, do not splash water on the device but wipe it out with smooth cloth or towel.

Contact your supplier in case of any problem!


Device Overview




Product PIN Diagram



Product Dimension & Installation




Mounting the device on wall




- 1 Paste the mounting template sticker onto the wall, and drill holes according to the mounting paper.
- 2 Fix the back plate onto the wall using wall mounting screws.
- 3 Insert the device into back plate.
- 4 Use security screw to fasten the device to back plate.

Bell & Wiegand Connection

External bell connection




Wiegand In connection



Lock Relay Connection


The system supports Normally Opened Lock and Normally Closed Lock. For example the NO LOCK (normally) opened.

Device not sharing power with the lock




Lock Relay Connection

Device sharing power with the lock




Ethernet Connection

LAN connection



Another way for ethernet connection




Note: The device can be connected to PC directly by ethernet cable.



ZK Building, Wuhe Road, Gangtou, Bantian, Buji Town, Longgang District, Shenzhen China 518129
Tel: +86 755-89602345
Fax: +86 755-89602394
www.zkteco.com




Wiegand Output Connection



9


RS232 Connection

Printer connect




10

Alarm Connection



11


Button & Sensor Connection




12

Power Connection

With UPS (Optional)



Without UPS




Recommended power supply

- 1) 12V ± 10%, at least 500mA.
- 2) To share the power with other devices, use a power supply with higher current ratings

13

Standalone Installation




14

Device Operation


Quick flows

- 1) Enroll Administrator and Users
 - a. Enroll Administrator (Main Menu>User Management>New User)



- User ID:** Enroll user ID; it supports 1-9 digits of numbers.
- User Role:** Select the user role. between Normal User and Super Admin.
- Fingerprint:** Enroll a fingerprint or fingerprints.
- Face:** Enroll face according to the prompts of screen and voice.
- Badge Number★:** Enroll a badge by swiping the badge.
- Password:** Enroll the password; it supports 1-9 digits of numbers.
- User Photo:** Enroll the user photo which will be displayed after verification.
- Access Control Role:** Set the Access Control parameters of the user.

Access Control Setting (Main Menu>Access Control) :




- Access Control Options:** Including Door Lock Delay, Door Sensor Delay, Door Sensor Type, NC / NO Time Period etc.
- Time Schedule:** Schedule Doors' opening time, 50 time zones are available to define.
- Holidays:** Set special time zones for holidays.
- Access Groups:** Set to manage employees in groups.

15

Device Operation

- Combined Verification:** Set various groups into a combined access group to achieve multi-verification.
- Duress Options:** Set duress function options.
- b. Enroll Normal Users (Follow the same steps of "Enrolling Administrator" except the "User Role" option)


- 2) Communication Settings (Main Menu>Communication)




- Ethernet:** The device can communicate with PC via the Ethernet parameters.
- Serial Comm:** The device can communicate with PC via the serial port according to the user-defined parameters.
- PC Connection:** Set the password and device ID so that you can connect the device with software in PC.
- Cellular Data Network★:** When the device is applied on a dial-up network, ensure that the device is within the coverage of the mobile network signals(3G).
- ADMS Setting★:** Settings used for connecting with ADMS server.
- Wi-Fi Setting★:** The device provides a Wi-Fi module, which can be built in the device mould or externally connected, to enable data transmission and to establish a wireless network environment.
- Wiegand Setup:** Set wiegand-out parameters.

- 3) Verification(1:1 verification mode for example)

Click [F1] to enter 1:1 verification mode on initial interface.



Enter User ID and press [OK].




When multi-verification mode is registered, please choose the verify mode as shown in the figure above: password, fingerprint and face.


16

Device Operation

- b. Fingerprint Verification Mode




- c. Password Verification Mode



- 4) Viewing Attendance Records


- a. View records in the device(Main Menu>Attendance Search>Attendance Record)



Enter the user ID to search.

Select the time range for attendance record query.

- b. View records on computer (Main Menu>USB Manager>Download>Attendance Data)




1. Insert the USB disk correctly.
2. Download the attendance data to the disk.
3. Upload the attendance data from the disk to your computer.
4. Name the downloaded data as "Device Serial Number.dat". You can open the downloaded data and view it.

17

Device Operation

Backup Data

To avoid data loss due to mis-operation, you can back up the data to local drive or USB disk at any time.



1. Enter Main Menu>Data Management>Backup Data>Saving Type>Data Type to backup.
2. Select the content to-be-backed up.

Other Settings



- a. Date Time (Main Menu>System>Date Time)
- Set the date, time and time format for the device.

Troubleshooting

- Q: "Invalid time zone" is displayed after verification?
A: Contact Administrator to check if the user has the privilege to gain access within that time zone.
- Q: Verification succeeds but the user cannot gain access?
A: 1. Check whether the user privilege is set correctly.
2. Check whether the lock wiring is correct.

If there is any problem when using the device, please visit www.zkteco.com and log on, and click [Support] --> [Trouble Ticket] to submit your question. Our technical team will provide you with technical support as soon as possible!

18